

ALL IN ONE

INDOCEM[®]

Paints
SINCE 1978

LUXURY EMULSION PAINT INTERIOR WALL FINISH



Product Description

ALL-IN-ONE Luxury Emulsion is an exquisite paint finish for the interior walls. It is a blend of superior quality of Pure Acrylic Emulsion, best available quality of pigments and additives. It renders an extraordinary perfect, even and smooth velvety finish with a soft pearl glow to your interior walls.

Technical Details

Areas of application	Smooth plasters, cement concrete, interior ceiling, asbestos sheet.
Form	Liquid
Thinning Medium	Fresh non saline clean potable water
Dilution	45% by volume i.e 450 ml of water to 1 Ltr of paint
Stability of thinned paint	To be used within 24 hours.
Application Method	Brush, Roller or Spray.
Drying Time-Surface dry	Surface dry time 30 minutes.
Recoating Time	6 hours.
Flash Point	N.A. Non-Flammable.
Finish	Smooth & silky rich sheen
Coverage	140-160 Sq. ft./ Ltr / 2 coats * * Actual coverage may vary depending on the method, condition of application, surface condition, roughness, porosity and shade.

Available Packs

01Ltr 04Ltr 10Ltr 20Ltr

Features



**LUXURIOUS
RICH SHEEN**



**EASY
WASHABILITY**



**FUNGUS
RESISTANCE**



**NO CHALK, CRACK
OR PEEL OFF**



**SMOOTH & EVEN
SPREAD ON WALL**



**STAIN
RESISTANCE**



**ECO FRIENDLY
LEAD / CHROME FREE**



**FAST
DRYING**

How to Apply

Pre – Painting

- ▶ All possible source of moisture & dampness must be checked & repaired. The structure must be completely moisture free.
- ▶ Allow newly plastered surfaces to be cured for a period of 28 days.

Surface Preparation

- ▶ Scrap the surface thoroughly to remove loose particles and paint flakes. The surface should be clean and free from dust, dirt, grease, oil etc.
- ▶ Previous coatings of lime wash must be thoroughly removed. Earlier coatings of oil / emulsion paints, if in good condition, need not be removed. However, the gloss or sheen of such coating must be removed by thorough sanding.

Paint Application Process

- ▶ Sand the surface with sand paper 180 and wipe clean.
- ▶ Apply one coat of Indoprime Plus Cement Primer (W.T) diluting with 80% clean potable water. Allow 4 – 6 hours for recoating.
- ▶ Apply a coat of Indocem Acrylic Wall Putty or Wall Magic Cement based Wall Putty. Allow to dry for 6 hours.
- ▶ Sand the surface and wipe clean.
- ▶ Apply another coat of Indoprime Plus Cement Primer (W.T) diluting with 80% clean potable water. Allow to dry for 6 hours before recoating.
- ▶ Apply first coat of All In One Luxury Emulsion diluting with 40% of clean potable water. Allow to dry for 6 hours before recoating.
- ▶ Apply a second coat of All In One Luxury Emulsion as per first coat.

Post Application Instructions

- ▶ For removing stains, sponge clean with a mild soap solution and wipe clean. Ensure a drying time of 2 weeks before cleaning.

Precautions & Safety Measures

- ▶ Fresh plaster should be properly cured with plenty of water, for minimum 4 weeks.
- ▶ Fungus affected areas need to be given a separate treatment.
- ▶ Stir the paint well & strain before use.
- ▶ Do not over thin the paint and over extend the brush.
- ▶ Do not keep water-mixed material.
- ▶ Do not apply during wet or frosty weather.
- ▶ Do not breathe vapour of the paint. Wear a suitable mask.
- ▶ In case of contact with eyes, rinse immediately with plenty of water. Consult a physician.
- ▶ Keep out of reach of children and away from food, drink and animal feed etc.
- ▶ Containers should be tightly closed after each use. Store in a cool & dry place.
- ▶ Do not pour leftover paint down the drains, dispose off safely.

Information in this leaflet is given in good faith, but without warranty, as conditions of storage and use vary and are beyond our control.

**Conditions apply*