

PREMIUM PLASTIC EMULSION PAINT INTERIOR WALL



The Product

Sapphire Premium Emulsion is a **Pure Acrylic Emulsion** paint for application on interior walls. Sapphire renders smoother finish and slight sheen, superior anti-fungal property, and improved durability to walls. Sapphire also gives **better washability, better coverage and brighter look**. Your dream home reflects a touch of class and lavish life style when painted with Sapphire Premium Acrylic Emulsion.

Technical Details

Areas of application	All types of smooth plasters, false ceilings, concrete and asbestos sheet etc.
Form	Liquid
Thinning Medium	Non-Saline clean potable water.
Thinning Ratio	Approximately 450ml to 500ml water to 1 litre of paint.
Stability of thinned paint	To be used within 24 hours.
Application Method	Brush, Roller or Spray.
Drying Time-Surface dry	Surface dry time 30 minutes.
Recoating Time	An interval of 6 hours is desired.
Flash Point	N.A. Non-Flammable.
Coverage	90-100 Sq. Ft / Ltr / 2 coats. (It may vary depending on the method and condition of application, mixing, surface condition, porosity and sometimes on shade)
Finish	Mild Sheen.

Features



**SOFT MILD
SHEEN**



**EASY
WASHABILITY**



**SMOOTH & EVEN
SPREAD ON WALL**



**FUNGUS
RESISTANCE**



**SAFEGUARD
WALL**



**ECO FRIENDLY
LEAD / CHROME FREE**



**STAIN
RESISTANCE**



**NO CHALK, CRACK
OR PEEL OFF**

How to Apply

Pre Painting

- ▶ Proper preparation of surface is the key to a professional and long lasting finish. All possible sources of moisture must be checked and repaired. All leakages and dampness must be stopped completely. Fungus and algae must be removed completely. Paint will not adhere to damp, wet, dirty, slick or unsealed surfaces and surfaces bearing efflorescence.
- ▶ Remove loose particles, previous coat of paint, lime wash etc. thoroughly by scrapping either with wire brush or any conventional method. Ensure surface is free from dirt, dust, grease, moisture, fungus, algae etc.
- ▶ Make the wall dent free, smooth and even.
- ▶ If surface to be painted is new, it must be allowed to cure for 28 days before painting.

Paint Application Process

- ▶ Sand the surface with sand paper 180 and wipe clean
- ▶ Apply one coat of Indoprime Plus Cement Primer (WT) diluting with 80% clean potable water. Allow 4-6 hours for recoating.
- ▶ Apply a coat of Indocem Acrylic wall putty or Wall Magic Cement Based Wall Putty. Allow to dry for 6 hours Sand the surface and wipe clean.
- ▶ Apply another coat of Indoprime Plus Cement Primer (WT) diluting with 80% clean potable water. Allow to dry for 6 hours before recoating
- ▶ Apply 1st coat of Sapphire Premium Emulsion diluting with 40% of clean potable water. Allow to dry for 6 hours before recoating.
- ▶ Apply a second coat of Sapphire Premium Emulsion as per first coat.

Precautions & Safety Measures

- ▶ Do not over thin paint or over extend the brush.
- ▶ Do not apply in wet or frosty weather.
- ▶ Containers should be tightly closed after each use. Keep out of reach of children, and away from food, animal feed etc.
- ▶ Suitable mask/goggles/gloves should be used while handling the paint.
- ▶ In case of contact with eyes, rinse immediately with plenty of water. Remove splashes of paint with the help of soap and soft water. Consult a physician. Do not inhale, in case of inhalation, seek medical attention if symptoms persist. Avoid darkness and airless ness inside the room.
- ▶ Store in a cool and dry place away from heat, direct sunlight and source of ignition and fire.
- ▶ Do not pour leftover paint down the drains, dispose off safely.

Available Packs

01Ltr 04Ltr 10Ltr 20Ltr

Information in this leaflet is given in good faith, but without warranty, as conditions of storage and use vary and are beyond our control.

**Conditions apply*